



SCK GND
TP44 TP45 R40 TP48
3V8 TP40 PWDN
SDA0 R36 TP30
SCL0 TP47 Cam_VDD



TP39 SD_VDD

SD 2.0

USB_ON/OFF



CLK2 DAT2
TP1 TP2

